



Notiz



Power / Cable

- leuchtet bei Internetverbindung
- blinkt, wenn Internetverbindung unterbrochen ist

Fon

- leuchtet bei einem Telefonat
- blinkt bei Sprachnachrichten im Netz

DECT

- leuchtet, wenn DECT an ist
- blinkt, wenn Connect/WPS ausgelöst wird

WLAN

- leuchtet, wenn WLAN an ist
- blinkt, wenn Connect/WPS ausgelöst wird

Info

- blinkt bei Nachrichten auf dem Anrufbeantworter (einstellbar)
- leuchtet rot bei wichtiger Nachricht auf <http://fritz.box>

Connect/WPS-Taste

- drücken für WLAN- oder DECT-Gerät anmelden

DECT-Taste

- drücken für Telefone wiederfinden

Einstellungen ab Werk

Factory settings





Notes



Power / Cable

- lights up for active internet connection
- flashes when the internet connection is interrupted

Fon

- lights up during a telephone call
- flashes when voice messages are waiting in the network

DECT

- lights up for active DECT
- flashes when Connect/WPC initiated

WLAN

- lights up when WiFi is on
- flashes when Connect/WPC initiated

Info

- flashes when messages are waiting on the answering machine (configurable)
- lights up red for important notification on <http://fritz.box>

Button Connect/WPS

- press to register wireless or DECT device

Button DECT

- press for telephone search

Eigene Einstellungen

Custom settings

WLAN-Funknetz (SSID)

Wireless radio network (SSID)

WLAN-Netzwerkschlüssel

Network key

FRITZ!Box-Kennwort

FRITZ!Box password