











<b>A</b>  M4x12mm x2	<b>B</b>  M5x12mm x2	<b>C</b>  M6x12mm x1	<b>D</b>  M8x12mm x1	<b>E</b>  Washer x1	<b>F</b>  Bobbin x1	<b>G</b>  M5x16mm x1	<b>H</b>  Allen key
---	--	--	--	---	---	--	--

Included  
Inclus  
Inbegriffen  
Incluido

Also required  
Également requis  
Ebenfalls benötigt  
También se requiere

Pozi-drive  
  
Suitable fixings  


1 EN Assemble to suit your TVs VESA pattern FR Assemblez en fonction du schéma VESA de votre TV DE Montage passend zur VESA-Bohrung Ihres Fernsehers ES Compatibilidad con interfaces de montaje VESA para su televisor

1

?

1

VESA 75 / 100

?

1

VESA 200 / 300 / 400 / 600

i

EN Wall Installation  
FR À Installation murale  
DE Wandinstallation  
ES Instalación en pared

